

48701 - Artwork Instructions

- 1. Place your artwork within 2. Once your artwork has the outlined box on the template. Ensure no part of the design extends outside the box, as it will not fit inside the sign holder.
 - been placed, print it on an A4 sheet of paper. 3. After printing, use the box outline and trim marks as a guide to cut out the artwork neatly.
- 4. Following the dotted line, fold the artwork in half to create a clean crease along the middle. 5. Finally, slide the folded insert into the 48701 Sign Holder.

For more information, email us at info@jpmark.com.au or contact us at 03 9729 9777 to find out more regarding the Deflecto Sign Holder Desk Tent Style - A5 Folded.